

## Waterproof DS18B20 Sensor Kit (Simple)

- 1. Liitä Arduino Uno Wifi Rev2 USB-johdolla tietokoneeseen.
- 2. Yhdistä sensori(t) ja Arduino Uno Wifi Rev2 toisiinsa seuraavalla tavalla:




3. Avaa Arduino IDE.

4. Tarkista, että kohdissa "Kortti", "Portti" sekä "Registers emulation" lukee alla olevat tekstit (Huom! Portin nimi riippuu omasta koneestasi / käyttöjärjestelmästä):



- 5. Lataa kirjastot "OneWire.h" sekä "DallasTemperature.h" täältä (jollei sinulta löydy jo): <a href="https://www.arduinolibraries.info/libraries">https://www.arduinolibraries.info/libraries</a>
- 6. Asenna kirjastot täällä: Sketsi/Sisällytä kirjasto/Ylläpidä kirjastoja...
- 7. Lataa koodi "Simple" täältä:



8. Tarkista koodi painamalla sekä siirrä koodi Arduino Uno WiFi Rev2 –laitteeseen painamalla ::



9. Käy kurkkaamassa tulostusta sarjamonitorista [22] (jos ei mene automatic). Pitäisi tulla jotain vastaavaa:

```
/dev/ttyACM3 - + ×

Lähetä

14:40:30.051 -> Requesting temperatures...DONE

14:40:30.714 -> Temperature for the device 1 (index 0) is: 25.69

14:40:31.409 -> Temperature for the device 1 (index 0) is: 25.94

14:40:31.402 -> Requesting temperatures...DONE

14:40:32.105 -> Temperature for the device 1 (index 0) is: 26.37

14:40:32.138 -> Requesting temperatures...DONE

14:40:32.800 -> Temperature for the device 1 (index 0) is: 26.81

14:40:33.800 -> Temperature for the device 1 (index 0) is: 27.19

14:40:33.529 -> Requesting temperatures...DONE

14:40:34.191 -> Temperature for the device 1 (index 0) is: 27.56

14:40:34.257 -> Requesting temperatures...DONE
```